


## MILLAGE MOSCOW COLLECTION MANUAL



**INDICATION:** During the calendar jump phase between **10.30 pm and 00.00 am** the date can be changed. In this case the date of the following day needs to be set as there will be no jump at midnight.

### Stem position 1

- Home position, watch runs

### Stem position 2

- Quick change of the date (↻ clockwise), watch runs
- Quick change of 24h indication (↻ anticlockwise), watch runs

### Stem position 3

- Hand-setting, watch stops
- when stem pulled out, save up to 70% energy